

CALIBER® BunkWrap 16'

2"x 4"x 16' 23050 – GRAY

READ ALL INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION

TOOLS REQUIRED:

- Power drill (T-20 Torx bit Included)
- Pencil
- Sharp utility knife and speed square
- Tape Measure

HARDWARE INCLUDED:

<u>Qty</u>	<u>Description</u>
1	16' (2x4) BunkWrap
4	(2x4) end caps
1	33 pk. of SS screws - 16' kit
1	8 pk. of SS screws - 2x4 kit
2	Velcro Straps

NOTE: If you are concerned about Scratching your Gel-Coat Hull, DO NOT USE THIS PRODUCT.

TIP: If you are using product on your trailer, and have a gel-coat hull, keep BunkWrap and hull free of surface debris to help eliminate scratching.

NOTE: Apply to solid wood only. If your bunk boards are rotted, screws will not hold BunkWrap in position.

- Step 1:** Remove carpet. BunkWrap will not conform to bunk boards with carpet still installed.
- Step 2:** “Optional” Remove bunks. Mark the BunkWrap where the bunk boards attach to the trailer (Score with knife/marker) to ensure correct replacement of BunkWrap material. Removal of bunk boards from trailer brackets eases installation.
- Step 3:** Unroll BunkWrap and place on top of bunk boards (Place board on top of BunkWrap if boards were removed). Measure bunk boards and/or mark BunkWrap, cut 1/16” shorter than bunk board length. **To cut:** score with a new blade and speed square. Bend at 90 degrees for a clean break. Remove any sharp edges or burrs from the wrap if needed. (Do not install BunkWrap at this point)
- Step 4:** Place end caps on ends of bunk boards, and secure through screw pockets with the proper quantity needed. (2x4 – 2 screws/end cap)
- Step 5:** Center bunk board on inside of BunkWrap (upside down if bunk board is removed from trailer or lift). Fold BunkWrap around bunk board, and end caps, while checking length and center alignment.
- Step 6:** Secure one end of the BunkWrap material by adding the first Velcro strap. Move to the opposite end of the bunk, and place your second Velcro strap 6” in from the end of the bunk. This will allow you to place your first two screws. Fasten the BunkWrap in place.
- Step 7:** Continue adding fasteners every 12”, while sliding the second Velcro strap up the bunk to hold the wrap in place, until BunkWrap material is fully-secured to the bunk boards. Remove both Velcro straps when complete.
- Step 8:** Reattach bunk boards on trailer bracket mounts. Trim away any interfering material so bracket sits directly on wood (secure any loose corners). If existing holes are stripped move slightly and relocate for secure fastening.

WARNING: These products are only designed to reduce resistance created when loading/unloading watercraft. Surfaces are slippery, especially when wet. Extreme caution should be taken when walking or climbing on any trailer in which any Caliber products are installed.

CALIBER, INC. LIMITED LIFETIME WARRANTY: Caliber, Inc. warrants that this product will be free from defects in material or workmanship under normal use, installation and service. Caliber, Inc. reserves the right, before having any obligation under this limited warranty, to inspect the damaged Caliber product. All warranty shipping costs for inspection shall be borne solely by the purchaser. This limited warranty is non-transferable. Contact Caliber, Inc. at www.caliberproductsinc.com or at 952-985-9999 for warranty service procedures.

DISCLAIMER: Caliber, Inc. shall not be liable for any special, incidental or consequential damages, including, but not limited to, lost revenues, lost profits, personal injury, damage to property, and third-party claims, arising out of any warranty, contract, statutory or tort. Notwithstanding the term of any limited warranty or any warranty implied by law, or in the event that any limited warranty fails of its essential purpose, in no event will Caliber's entire liability exceed the purchase price of this product.

CALIBER®

952-985-9999

www.caliberproductsinc.com

Assembled on 19 May 2020

C:\Users\GregW.DOMAIN\Dropbox (Caliber Dropbox)\Caliber Dropbox Team Folder\Instructions\23050 - 2x4x16 GRAY BUNKWRAP - 16' .docx